



CABINET PARTS



CABINET PARTS

Illus No.		DESCRIPTION	Illus No.		DESCRIPTION	Illus No.		DESCRIPTION
1	1101	Literature Parts	17		Terminal, Tinned	33		Strike, Door
ı	W10114104	Tech Sheet	''	279310	& Brass (3)	34		Palnut (10)
	W10114194 W10114206				(Includes Illus. 39)	35	300433	Door Inner
	W10114200	Quick Start	18		Cabinet	33	8565037	
	W10088777	Use & Care Guide	'Ŭ	8557569			8575052	
	***10000777	Osc a Care Carae		W10045390		36	0070002	Door, Outer
2	343641	Screw, 10-16 x 1/2	19		Gasket, Inner Door		8565042	
3		Screw, 8–18 x 3/8	20		Spring, Idler		8575025	
4		Clip, Ground (2)	21		Panel, Front	37	00.00=0	Door Handle
5		Cover, Block		8565029			W10050120	
6		Lock-Top Front (2)		8565032			W10050100	
7		Panel, Rear	22	8566208	Switch Assembly	38		Seal, Front Panel
8		Plug-Hole	23		Clamp, Motor	39		Terminal Block
	3404413		24		Catch, Door			Kit (For
	3404416	Black			Assembly			Terminal Block)
9	8568303	Locator,	26		Screw, 10-16 x 1/2	40	342055	Screw, 10-32 x 5/8
		Snap Down	27	3390631	Screw, 8-18 x 1/2	41		Block, Terminal
10	3978977	Door Switch	28		Hinge, Assembly	42		Pulley Assembly
		Assembly		8565018		43		Belt, Drive
11	3389420	Retainer, Idler		W10050090	Black	44	8547166	Base, Motor
12	8575027	Seal, Door	29		Bracket, Switch	45	W10002600	
13		Pal Nut (4)	30	8539897	Belt-Switch			6–20 x 1 1/4
14		Restrainer, Belt			Jumper	46		Pulley, 60 HZ
15	3394083	Clip, Front	31	8533974	Screw Ground	47	8566152	Motor Assembly
		Panel (2)	32		Window, Outer Door			60 HZ.
16	3392100	Foot, Dryer		W10116398		48		Hinge, Top (2)
	279810	Foot-Optional		8575049	Black	49		Glass, Inner Door
		(Extended Length				50	W10100830	
		Package of 2)				- 4		10–16 x 3/64
		(Not Included)				51	18849	Pad-Top Hinge
			I					


TOP AND CONSOLE PARTS



TOP AND CONSOLE PARTS

Illus No.		DESCRIPTION
		22001111 11011
1	337686	=
2	8558863	
3 4	237446	
4 5	W10051096	User Interface Panel, Console
3	W10120084	
	W10120085	
6	3196537	Screw, 8–18 x 5/8
7	8564265	
8	W10003770	Screw, 6-19 x 3/64
9	W10110196	Knob, Assembly
10	8572270	Assembly,
4.4		Lint Screen
11		Cover, Lint Screen
	W10044320	
	W10044360	
12	W10044470	
	W10044480	
13	W10001580	Screw
15	3395683	
4.0		(Motor)
16	0565005	Top
	8565025 8565028	
17	W10111609	Control,
17	W10111005	Electronic
18	3394427	Clip-Harness
19	8563853	Bracket,
		Machine Controller
22		Grommet
23	8299914	
25		Connector
26	94614	
27	3397269	Connector, Timer

BULKHEAD PARTS



BULKHEAD PARTS

Illus No.		DESCRIPTION
1	8544805	Lint Chute
2	487909	Assembly Screw, 8–15 x 1/2
3	3387459	Washer–Support
3 4	347139	Seal, Lint Chute
5	90767	Screw, 8–18 x 3/8
6	8573836	
8	8566498	Thermostat, HI–Limit
9	W10169881	Kit, Thermal Cut-Off
		(Includes
10	694089	Illus. 8) Wheel, Blower
11	8577230	Housing, Blower
12	8546149	Clip-Heater Box
13	343641	Screw, 10–16 x 1/2
14	8544801	Box, Heater
15	W10053480	Bracket,
4.0	0077070	Lint Chute
16	3977373	Bracket, Drum Light
17	8573069	Element, Heater
18	8544813	Seal
19	279457	Wire Kit, Terminal
		(For Heater
		Element Wiring
00	400 400	Harness Repair)
20	489463	Screw, 8–18 x 5/8
21 22	3196537 3406126	Screw Bulb
23	8558890	Bulkhead, Front
24	3402841	Lens, Drum Light
25	690997	Ring Tri
26	8575325	Shaft, (L.H.)
27	8575324	Shaft, (R.H.)
28	8536973	Shaft, (R.H.) Roller, Support
29	W10001120	Nut, 3/8–16
30	8576468	Assembly, Sensor
31	8557242	Bulkhead, Rear
32	3934666	Nut 3/8–16 (R.H.)
35	8557277	Seal Drum (2)
36	W10109200	Screw, 11-16 x 3/4
37	8557270	Drum, Assembly
38	8565688	Baffle, Drum (3)
39	3403634	Socket Assembly
40 41	8577274	Thermistor
41	8544810	Collar, Lint Chute

OPTIONAL PARTS (NOT INCLUDED)

For Model: MED6400TQ0, MED6400TB0 (White) (Black)

Illus. Part

No. No. DESCRIPTION

ACCESSORY PARTS

279948 Kit, Dryer Repair W10071550 Dry Rack 8522199 Kit, Dryer Vent Testing

PAINT, TOUCH-UP (1/2oz.)

72017 White 4392899 Biscuit 72032 Black

PAINT, PRESSURIZED SPRAY

(12 oz.)

350930 White 4392901 Biscuit 285006 Black 350938 Primer, Gray

PAINT, BULK (1 qt.)

799344 White (Uncut)